



Pair Apriva Reader with PDCD

1. Disconnect the **USB cable** connecting the handheld to the PC
 - Disconnect from the PC side
2. Use the USB adapter that converts the USB Type A to the Mini-B
 - Type A is the larger, flat connector
 - Mini-B is the smaller connector
 - this adapter should be included in the Apriva reader box
3. Plug the **USB adapter** into the **Apriva reader**, plugging it into the PDA port
 - port names are on the front bottom location of the reader, above the ports
4. If the **Card reader** is on, turn it off.
5. Turn the Card reader on.
6. Go to **Windows > Settings > System > Apriva Reader**
7. If **USB** is not selected, select it.
8. Click the **Test connection** button.
 - If you have the card reader on, connected to the correct port and have restarted the card reader, you should get a pop-up
 - *Test connection. Connection to smart card reader is working*
 - If you do not get this message, make sure the cable is plugged into the correct port and restart the card reader.
9. Click the **Pair** button. This will take a few moments for it to complete.
10. Once this is done you should get the message
 - *Bluetooth Pairing Paring complete. You may now use the Bluetooth to connect to your reader*
 - It might say something else if you didn't have the device paired before.
11. Click on the **Bluetooth** radio button.
12. Disconnect the **card reader** then click the **Test Connection** button. It should say
 - *Test connection. Connection to smart card reader is working.*
13. The reader is now paired with your device.

